

Note: Refer to the C49 Owner's Manual page 7 for additional connection information. Turntable with Moving Coil Cartridge Connection Legend: Data Cable*-Digital Signal Cable -RS232 Cable -Sensor/Keypad Cable -Power Control Cable* -Ground Wire -Audio Signal Cable -AC Power Cords -Video Signal Cable -Loudspeaker Cable -RF Signal Cable -* 2 conductor shielded with 1/8 inch stereo mini phone plug on each end. Media Bridge UNBALANCE DC IN
12V

Use Celly The
Power Adapter
Provided USB 3.0 2.1 AMPS 2.1 0 0 4 4 PHONO INPUTS UNBAL FIXED UNBAL UNBAL AM/FM Tuner 4 IGITAL AUDIO INPUTS

MCT OPTICAL 2 OPTICAL 1 RAA2 AM ANT POWER CONTROL EXTERNAL CONTROL DATA PORTS USB AUDIO 0 0 C€ Milntosh ⟨₽⟩ 0 C49 AUDIO PREAMPLIFIER X Connect to (🗵 SERIAL NUMBER AC Outlet SACD/CD Transport DIGITAL AUDIO OUTPUTS Digital Audio Player Computer (DIGITAL UNBAL UNBAL

O COAX
OPTICAL OPTICAL

OPTICAL

OPTICAL

OPTICAL

OPTICAL

OPTICAL

OPTICAL

AUL SERIAL NUMBER DC IN 5V

Use Only The Power Adapter Provide C € SERIAL NUMBER



Note: Refer to the C49 Owner's Manual page 8 for additional connection information.

